

# General Specifications

## MODEL UT550 Digital Indicating Controller



GS 05D01C02-01E

### General

Model UT550 Digital Indicating Controller is an intelligent, micro-processor based digital indicating controller with powerful control capability and the user-friendly large numerical display. The UT550 features as standard many functions which are necessary for various control applications, and all of these functions such as control function, control computation function, signal computation function, etc. can be configured by using the keys on the front panel. The instrument has eight types of control strategies and also an overshoot suppressing function "SUPER" and a hunting suppressing function "SUPER 2" as well as an auto-tuning function built in as standard. It is suitable for a diverse range of applications, with position-proportional control model and heating/cooling control model also available.

### Main Features

- Extra-large digital display allows the indicated values to be read even from a long distance. LEDs of 20 mm height are used for the process variable display. This is a five-digit display for higher resolution.
- Eight types of control function, including single-loop control, cascade control, loop control with PV auto-selector, and loop control with PV-hold function, enabling the operator to start control operation immediately after simply entering the settings.
- Parameters can be easily set using a personal computer. ("Parameter setting tool (model LL100)" sold separately is required.)
- Universal input and output enables users to set or change freely the type of PV inputs, PV input range, type of control output, etc. from the front panel.
- In addition to standard type (universal output), the position-proportional type (relay output) or the heating/cooling type (universal output) can be specified.
- Contact inputs (up to 8 points) and contact outputs (up to 8 points) can be employed and functions can be assigned to each contact. (The maximum number of points varies the suffix code.)  
Note: See Hardware Specifications and Contact Outputs described later.
- Various communication function are provided. Communication is possible with personal computer, programmable logic controller, and other controllers.

### Functional Specifications

#### Control Functions

##### UT Mode

The following types of basic control structure can be set as the UT mode by the user.

- Single-loop control (UT mode 1):  
The most simple and basic control function.

### UT550



UT550E  
"E" indicates the model with expanded functions.



#### Cascade primary-loop control (UT mode 2):

Output tracking function and cascade control logic are provided. Suitable for cascade primary-loop control.

#### Cascade secondary-loop control (UT mode 3):

Setpoint output and cascade control logic are provided. Suitable for cascade secondary-loop control.

#### Cascade control (UT mode 4):

Dual control function for cascade control is available in a single instrument.

#### Loop control for back-up (UT mode 5):

Output tracking function is provided to back up another control instrument. The local and remote control outputs are switched by a contact input.

#### Loop control with PV switching (UT mode 6):

Two PV inputs are switched for control depending on the status of contact input or PV input.

#### Loop control with PV auto-selector (UT mode 7):

Two PV inputs are automatically selected for control with a high, low, average, or temperature-difference value selector.

#### Loop control with PV-hold function (UT mode 8):

This control holds a PV input and a control output if an external sensor is switched.

### Control Computation Functions

In each UT mode, the following control computation functions can be selected:

Continuous PID control, Time-proportional PID control, Relay ON/OFF control, Position-proportional PID control (for UT550-1□, UT550-4□) and Heating/Cooling control (for UT550-2□).

#### Target setpoint and PID parameters:

Maximum eight sets of target setpoint and PID parameters can be set. These eight sets can be set for both the main and slave loops in cascade control.

- Zone PID selection:**  
Dividing PV input range into maximum 7 zones by maximum 6 reference points, PID parameter set switching in up to 7 PV input zones.
- Auto-tuning:**  
Available as standard. Possible to activate auto-tuning for both main and slave loops for cascade control.
- "SUPER" function:**  
Overshoots generated by abrupt changes in the target setpoint or by disturbances can be suppressed.
- "SUPER 2" function:**  
This function stabilizes the state of control that is unstable due to hunting, etc. without requiring any change in PID constants, when the load and/or gain varies greatly, or when there is a difference between the characteristics of temperature zones.
- Preset output function:**  
When the instrument is in STOP mode, PV input is burnt-out, or an abnormality is found in an input circuit, a preset value is output as a control output.
- Sampling period**  
Each sampling period can be selected under the following conditions:
- 50 ms: Available for model code UT550-00, when UT mode is set to Single-loop control and the following functions are not used: "SUPER" function, "SUPER 2" function, heating/cooling control, PV input computation, setpoint rate-of-change limiter, MV output rate-of-change limiter, deviation alarm, sensor grounding alarm, fault diagnosis alarm, and FAIL output.
  - 100 ms: Available when UT mode is not cascade control.
  - 200 ms: Available when UT mode is cascade control. (Set value when shipped from the factory: 200 ms)
  - 500 ms: Always available.

**Operation Mode Switching**

(Note: Communication enables all the following mode switching to be executed.)

- AUTO/MANUAL switching:**  
Bumpless switching between automatic operation mode and manual control mode is available by using the front keys or contact input. The contact input has priority over front key input or switching by communication. The contact input is invalid for Cascade secondary-loop control or Cascade control.
- RUN/STOP switching:**  
Switching by contact input (bumpless for switching from STOP to RUN). The contact input has priority over switching by communication. In RUN mode, control computation is activated. In STOP mode, control computation ceases and a preset value is output as a control output while other functions operate normally.

- REMOTE/LOCAL switching:**  
Switching between remote setpoint and local setpoint by instrument operation or contact input. The contact input has priority over instrument operation or switching by communication. For remote to local switching, either bumpless tracking (employing the remote setpoint on switching as the local setpoint) or without tracking (directly switching the local setpoint) can be specified.
- CASCADE/AUTO/MANUAL switching:**  
Switching by instrument operation or contact input. The contact input has priority over instrument operation or switching by communication. Valid for Cascade secondary-loop control or Cascade control.
- Output tracking ON/OFF switching:**  
Provided for Cascade primary-loop control or Loop control for backup. External tracking signal and internal control output are switched by the contact input. The contact input has priority over the switching by communication.

**Control Parameters Setting Range**

- Proportional band: 0.1 to 999.9%  
0.0 to 999.9% (for heating/cooling PID control), 0.0% available for ON/OFF control
- Integral time: 1 to 6,000 s, or OFF (for Manual reset)
- Derivative time: 1 to 6,000 s, or OFF
- ON/OFF control hysteresis: 0.0 to 100.0% of PV input range span
- Preset output: -5.0 to 105.0% (0 mA or less cannot be output)
- Output limiter:  
Setting range: -5.0 to 105.0% for both high and low limits  
However, "low limit setpoint < high limit setpoint" must be satisfied.  
In case of heating/cooling PID control, upper limiter for heating and upper limiter for cooling.
- Shutdown function:  
When manual control is carried out with 4 to 20 mA output, control output can be output down to about 0 mA (shutdown is specified for -5.0% or less).
- Rate-of-change limiter for output:  
OFF or 0.1 to 100.0%/s
- Deadband for heating/cooling control:  
-100.0 to 50.0% for output value
- Deadband for position-proportional control:  
1.0 to 10.0% for output

**● Configuration of Input/Output Signal**

**PV Input Computations**

Input processing, Square root extraction (voltage input only, Input low cut 0.0 to 5.0%), Ten-segment linearizer function, Ten-segment bias, Bias addition (-100.0 to 100.0%), and First order lag filter (OFF, time constant 1 to 120 s)

**Auxiliary Input Computations**

(Applied to remote setting input only)  
Input processing, Square root extraction (Input low cut 0.0 to 5.0%), Bias addition (-100.0 to 100.0%), Ratio multiplication (0.001 to 9.999), First order lag filter (OFF, time constant 1 to 120 s)

## ● Alarm Functions

Alarm types:

PV high limit, PV low limit, Deviation high limit, Deviation low limit, Deenergized on deviation high limit, Deenergized on deviation low limit, Deviation high and low limits, High and low limits within deviation, Deenergized on PV high limit, Deenergized on PV low limit, SP high limit, SP low limit, Output high limit, Output low limit.

Alarm setting range:

PV/SP alarm: -100 to 100% of PV input range  
 Deviation alarm: -100 to 100% of PV input range span  
 Output alarm: -5.0 to 105.0% of output value  
 Alarm hysteresis: 0.0 to 100.0% of PV input range span

Delay timer:

0.00 to 99.59 (minute, second)  
 An alarm is output when the delay timer expires after the alarm setpoint is reached. Setting for each alarm is possible.

Stand-by action:

Stand-by action can be set to make PV/deviation alarm OFF during start-up or after SP change until SP reaches the normal region.

Timer function (stabilization of control status notification event) (Alarm 1 only):

This function sets the alarm 1 output to ON when a preset time (timer setting) elapses after a PV has reached the control target setpoint hysteresis band to notify that control has reached its stabilized status. Restarted in RUN/STOP or SP switching.

Other alarm actions:

Sensor grounding alarm: Detects sensor deterioration and outputs an alarm.  
 Fault-diagnosis alarm: For input burnout, A/D conversion error, or thermocouple reference junction compensation error.  
 FAIL output: Abnormality in software or hardware.

Number of alarm settings: 8 (maximum)

The alarm status can be read via communication in addition to output as the above alarm output.

Alarm output points (see also the item "Contact Outputs")

- Number of contact (relay) outputs:  
 3 (standard) or 4 (if a control output relay is used for the alarm 4 output relay.)
- Number of contact (transistor open collector) outputs:  
 4 (when optional function code is specified as 1 or 3)

From the above, up to 8 point outputs can be obtained (except for cascade control).

Any of PV alarm, deviation alarm, SP alarm, output alarm, Fault-diagnosis alarm, sensor grounding alarm and FAIL output can be assigned to contacts for the above number of outputs. However, the timer delay alarm can be assigned to the alarm 1 output only. Also, the alarm 4 only can be assigned to the control output relay (if a relay is not used for control output).

## ● Display and Operation Functions

### PV Display

PV is displayed in the 5-digit display. PV1 or PV2 is displayed by switching them in cascade control. The number of display digits is 4 or 5. For thermocouple or RTD, data below the decimal point can be set not to display. The display range is -19999 to 30000 and the display span is 30000 or less. [550.00 appearing in the product photograph on page 1 cannot actually be displayed.]

### Setpoint Display

A parameter name is displayed in the 3-digit display and data in the 5-digit display. There are four kinds of displays : operating display, operating parameter setting display, setup parameter setting display and SELECT display.

Operating display:

Data necessary for operations, such as setpoint or control output, are displayed depending on the UT mode.

Operating parameters setting display:

The Operating parameters, which are mainly changed during operations, such as PID constant, are displayed.

Setup parameters setting display:

The Setup parameters to configure the functions of the instrument before starting operation are displayed.

UT mode is to be set in this display.

SELECT display:

Up to five displays which are frequently accessed can be selected from the Operating parameters setting display and Setup parameters setting display to be displayed in the SELECT display.

### Status Indicator Lamps

Alarm indicator lamps:

Four lamps, AL1, AL2, AL3, and AL4

Status indicator lamps:

REM (remote operation), MAN (manual mode operation), CAS (cascade operation), and LP2 (cascade secondary-loop control)

Deviation monitor:

▲Plus deviation, ▼Minus deviation, and ■ deviation in normal range

### Operation Keys


△, ▽ keys: Increase or decrease setpoints and other parameters displayed in the setpoint display.

SET/ENT key: Used for setting or changing set data, switching the displayed contents, and switching operation modes except for A/M.

A/M key: Operation mode switching (Auto/Manual)

### Security Function

Key-lock by parameter setting and prohibiting operation by a password are available.



● **Communication Functions**

(For optional function code □1 or □2 only)

This controller has four types of communication protocol with one communication interface. Communication is possible with personal computer, programmable logic controller, and other controllers.

**Communication Protocol**

Computer link communication:

Communication protocol with a personal computer

Ladder communication:

Communication protocol with the ladder program on some programmable logic controllers.

Coordinated operation:

Protocol for coordinated operation with more than one GREEN SERIES controller. The UT550 controller can be connected as a master or slave station.

MODBUS communication:

Communication protocol with a personal computer, or PLC.

**RS-485 Communication Interface**

The RS-485 communication interface (conforms to EIA RS485) can be used for personal computer link, MODBUS communication, ladder communication, or for coordinated operation.

Maximum number of connectable controllers:

31 GREEN SERIES controllers

Maximum communication distance: 1200 m

Communication method:


Two-wire half-duplex or four-wire half-duplex, start-stop synchronization, and non-procedural

Baud rate:


600, 1200, 2400, 4800, or 9600 bps

**Examples of Communication System Configuration Diagram**


**(1) Personal computer link communication/ MODBUS communication**



**(2) Ladder communication**



**(3) Coordinated operation**



## ■ Hardware Specifications

### ● Input/Output Signal Specifications

#### PV Input Signal

Number of input points: 1

Input type, instrument input range, and measurement accuracy:

The type of input and instrument input range can be specified from the instrument input range codes shown in the table below.

Sampling period: 50, 100, 200, or 500 ms (selectable)

Burnout detection:

Activated for thermocouple (TC) input, RTD input, or standard signal of 0.4 to 2 V DC or 1 to 5 V DC.

Possible to specify a travel of upscale, downscale, or off.

For standard signal input, set to burn out at 0.1 V or less.

Input bias current: 0.05  $\mu$ A (for TC or RTD b-terminal)

Measurement current(RTD): About 0.13 mA

Input resistance: 1 M $\Omega$  or more for TC or mV input  
About 1 M $\Omega$  for DC voltage input

Allowable signal source resistance:

250  $\Omega$  or less for TC or mV input

Signal source resistance effect

0.1  $\mu$ V/ $\Omega$  or less

2 k $\Omega$  or less for DC voltage input

Signal source resistance effect

About 0.01%/100  $\Omega$

Allowable wiring resistance (for RTD input):

Maximum 150  $\Omega$ /wire (Conductor resistance between three wires must be equal.)

However, it must be 10  $\Omega$ /wire for a maximum range of -150.0 to 150.0 $^{\circ}$ C.

Effect of wiring resistance:  $\pm 0.1^{\circ}$ C/10 $\Omega$

Allowable input voltage:

$\pm 10$  V DC for TC/mV/RTD input

$\pm 20$  V DC for DC voltage input

Noise rejection ratio:

Normal mode 40 dB (50/60 Hz) or more

Common mode 120 dB (50/60 Hz) or more

Reference junction compensation error:

$\pm 1.0^{\circ}$ C (15 to 35 $^{\circ}$ C),  $\pm 1.5^{\circ}$ C (0 to 15 $^{\circ}$ C and 35 to 50 $^{\circ}$ C)

Applicable standards:

JIS, IEC, and DIN (ITS-90) for TC and RTD

Input Type		Instrument Input Range Code	Instrument Input Range ( $^{\circ}$ C)	Instrument Input Range ( $^{\circ}$ F)	Measurement Accuracy*1	
Unspecified (When shipped from the factory)		OFF	Set the data item PV input type "IN 1" to the OFF option to leave the PV input type undefined.			
Thermocouple	K	1	-270.0 to 1370.0 $^{\circ}$ C	-450.0 to 2500.0 $^{\circ}$ F	$\pm 0.1\%$ $\pm 1$ digit of instrument range at 0 $^{\circ}$ C or more $\pm 0.2\%$ $\pm 1$ digit of instrument range at less than 0 $^{\circ}$ C • However, $\pm 2\%$ $\pm 1$ digit of instrument range for type K at temperatures less than -200 $^{\circ}$ C. • However, $\pm 1\%$ $\pm 1$ digit of instrument range for type T at temperatures less than -200 $^{\circ}$ C.	
		2	-270.0 to 1000.0 $^{\circ}$ C	-450.0 to 2300.0 $^{\circ}$ F		
		3	-200.0 to 500.0 $^{\circ}$ C	-200.0 to 1000.0 $^{\circ}$ F		
	J	4	-200.0 to 1200.0 $^{\circ}$ C	-300.0 to 2300.0 $^{\circ}$ F		
		5	-270.0 to 400.0 $^{\circ}$ C	-450.0 to 750.0 $^{\circ}$ F		
	T	6	0.0 to 400.0 $^{\circ}$ C	-200.0 to 750.0 $^{\circ}$ F		
		7	0.0 to 1800.0 $^{\circ}$ C	32 to 3300 $^{\circ}$ F		$\pm 0.15\%$ $\pm 1$ digit of instrument range at 400 $^{\circ}$ C or more $\pm 5\%$ $\pm 1$ digit of instrument range at less than 400 $^{\circ}$ C
	S	8	0.0 to 1700.0 $^{\circ}$ C	32 to 3100 $^{\circ}$ F		$\pm 0.15\%$ $\pm 1$ digit of instrument range
	R	9	0.0 to 1700.0 $^{\circ}$ C	32 to 3100 $^{\circ}$ F		
	N	10	-200.0 to 1300.0 $^{\circ}$ C	-300.0 to 2400.0 $^{\circ}$ F		$\pm 0.1\%$ $\pm 1$ digit of instrument range $\pm 0.25\%$ $\pm 1$ digit of instrument range for temperature at less than 0 $^{\circ}$ C
	E	11	-270.0 to 1000.0 $^{\circ}$ C	-450.0 to 1800.0 $^{\circ}$ F		$\pm 0.1\%$ $\pm 1$ digit of instrument range at 0 $^{\circ}$ C or more $\pm 0.2\%$ $\pm 1$ digit of instrument range at less than 0 $^{\circ}$ C • However, $\pm 1.5\%$ $\pm 1$ digit of instrument range for type E at temperature less than -200 $^{\circ}$ C.
	L (DIN)	12	-200.0 to 900.0 $^{\circ}$ C	-300.0 to 1600.0 $^{\circ}$ F		
	U (DIN)	13	-200.0 to 400.0 $^{\circ}$ C	-300.0 to 750.0 $^{\circ}$ F		
		14	0.0 to 400.0 $^{\circ}$ C	-200.0 to 1000.0 $^{\circ}$ F		
W (DIN)	15	0.0 to 2300.0 $^{\circ}$ C	32 to 4200 $^{\circ}$ F	$\pm 0.2\%$ $\pm 1$ digit of instrument range		
Platinel 2	16	0.0 to 1390.0 $^{\circ}$ C	32.0 to 2500.0 $^{\circ}$ F	$\pm 0.1\%$ $\pm 1$ digit of instrument range		
PR20-40	17	0.0 to 1900.0 $^{\circ}$ C	32 to 3400 $^{\circ}$ F	$\pm 0.5\%$ $\pm 1$ digit of instrument range at 800 $^{\circ}$ C or more Accuracy not guaranteed for temperature less than 800 $^{\circ}$ C		
W97Re3-W75Re25	18	0.0 to 2000.0 $^{\circ}$ C	32 to 3600 $^{\circ}$ F	$\pm 0.2\%$ $\pm 1$ digit of instrument range		
RTD	JPt100	30	-200.0 to 500.0 $^{\circ}$ C	-300.0 to 1000.0 $^{\circ}$ F	$\pm 0.1\%$ $\pm 1$ digit of instrument range (Note 1) (Note 2)	
		31	-150.00 to 150.00 $^{\circ}$ C	-200.0 to 300.0 $^{\circ}$ F	$\pm 0.2\%$ $\pm 1$ digit of instrument range (Note 1)	
	Pt100	35	-200.0 to 850.0 $^{\circ}$ C	-300.0 to 1560.0 $^{\circ}$ F	$\pm 0.1\%$ $\pm 1$ digit of instrument range (Note 1) (Note 2)	
		36	-200.0 to 500.0 $^{\circ}$ C	-300.0 to 1000.0 $^{\circ}$ F		
		37	-150.00 to 150.00 $^{\circ}$ C	-200.0 to 300.0 $^{\circ}$ F	$\pm 0.2\%$ $\pm 1$ digit of instrument range (Note 1)	
Standard signal	0.4 to 2V	40	0.400 to 2.000 V	Display range -19999 to 30000 Display span 30000 or less (Decimal point position changeable)	$\pm 0.1\%$ $\pm 1$ digit of instrument range	
	1 to 5V	41	1.000 to 5.000 V			
DC voltage	0 to 2V	50	0.000 to 2.000 V			
	0 to 10V	51	0.00 to 10.00 V			
	-10 to 20mV	55	-10.00 to 20.00 mV			
	0 to 100mV	56	0.0 to 100.0 mV			

Note 1: The accuracy is  $\pm 0.3^{\circ}$ C of instrument range  $\pm 1$  digit for a temperature range from 0 to 100 $^{\circ}$ C.

Note 2: The accuracy is  $\pm 0.5^{\circ}$ C of instrument range  $\pm 1$  digit for a temperature range from -100 to 200 $^{\circ}$ C.

\*1: Performance in the standard operating conditions (at 23 $\pm 2^{\circ}$ C, 55 $\pm 10\%$  RH, and 50/60Hz power frequency)

**Auxiliary Analog Input Signal**


(UT550-□1, -□2, or -□4 only)  
 Functions: Remote setting input, tracking input, cascade control secondary loop PV input, etc.  
 Input type: Settable within the range of voltage input 0 to 2 V DC, 0 to 10 V DC, 0.4 to 2.0 V DC or 1 to 5 V DC.  
 Number of inputs: 1 point  
 Sampling period: 100, 200 or 500 ms  
 Auxiliary analog input sampling period is linked with PV input sampling period.  
 (If PV input period is 50 ms, auxiliary analog input period is 100 ms.)  
 Input resistance: Approx. 1 MΩ  
 Input accuracy: ±0.3% ± 1 digit of input span for 0 to 2 V DC input  
 ±0.2% ± 1 digit of input span for 0 to 10 V DC input  
 ±0.375% ± 1 digit of input span for 0.4 to 2.0 V DC range  
 ±0.3% ± 1 digit of input span for 1 to 5 V DC range  
 Performance in the standard operating conditions (at 23±2°C, 55±10% RH, and 50/60Hz power frequency)

**Feedback Resistance Input Signal**

(UT550-1□ only) Valid for position proportional PID control.  
 Slidewire resistance:  
 Total resistance 100 Ω to 2.5 kΩ (with burnout detection of slidewire)  
 Measuring resolution ±0.1% of total resistance

**24 V DC Loop Power Supply for Sensor**

Supplies power to the 2-wire transmitter. The current signal is converted to a voltage signal by placing a resistor (arbitrary from 10 to 250 Ω) and is read by the PV input terminal.  
 21.6 to 28.0 V DC, maximum supply current about 30 mA (only for models with 24 V DC loop power supply for sensor).



**Retransmission Output**

Any of the PV, target setpoint or control output is output.  
 Or this can be used for 15 V DC loop power supply.  
 Number of output points: 1 or 2  
 Retransmission output 2 is available only when "relay" is selected as the control output type.  
 Output signal: 4 to 20 mA DC, 0 to 20 mA DC, 20 to 4 mA DC or 20 to 0 mA DC (0 mA or less cannot be output)

Load resistance: 600 Ω or less  
 Output accuracy: ±0.1% of span (±5% for 1 mA or less)  
 Performance in the standard operating conditions (at 23±2°C, 55±10% RH, and 50/60Hz power frequency)  
 When using for 15 V DC loop power supply:  
 Supply voltage 14.5 to 18.0 V DC, maximum supply current about 21 mA (with the protection circuit at field short-circuit).

**Control Outputs**

Select 1 or 2 points (UT550-2□) from the following output types depending on model type and UT mode. Relay contact output for position proportional PID control (UT550-1□ UT550-4□).

**Current output**  
 Number of output points: 1 or 2 (for heating/cooling type) (switchable to voltage pulse output)  
 Output signal: 4 to 20 mA DC, 0 to 20 mA DC, 20 to 4 mA DC or 20 to 0 mA DC  
 Load resistance: 600 Ω or less  
 Output accuracy:  
 ±0.1% of span (±5% for 1 mA or less)  
 Performance in the standard operating conditions (at 23±2°C, 55±10% RH, and 50/60Hz power frequency)

**Voltage pulse output**  
 Number of output points: 1 or 2 (for heating/cooling control) (switchable to current output)  
 Output signal:  
 ON voltage-12 V DC or more (load resistance 600 Ω or more)  
 OFF voltage- 0.1 V DC or less  
 Resolution: 10 ms or 0.1% of output value, whichever is greater

**Relay contact output**  
 Number of output points: 1 or 2 (for heating/cooling control)  
 Output signal: At three terminals of NC, NO, and Common  
 Contact rating: 250 V AC, 3 A or 30 V DC, 3 A (resistance load)  
 Resolution: 10 ms or 0.1% of output value, whichever is greater

**Contact Inputs**

Usage: Target setpoint switching, C/A/M mode switching, REMOTE/LOCAL switching, RUN/STOP switching, or PV input switching  
 Number of input points:  
 Varies with optional codes (as shown below):  
 UT550-□0: 2 points  
 UT550-□1: 8 points  
 UT550-□2: 3 points  
 UT550-□3: 7 points  
 UT550-□4: 3 points  
 Input type: Non-voltage contact input or transistor open collector input  
 Input contact rating: 12 V DC, 10 mA or more  
 On/off detection:  
 For non-voltage contact input,  
 On .. contact resistance 1 kΩ or less;  
 Off.. contact resistance 20 kΩ or more  
 For transistor contact input,  
 On .. 2 V or less;  
 Off.. leak current 100 μA or less  
 Minimum status detection hold time: PV input sampling period ×3

**Contact Outputs**

Usage: Alarm output, FAIL output

Number of output points:

Varies with optional codes (as shown below):

UT550-□0: Relay output 3 points

UT550-□1: Relay output 3 points, transistor output 4 points

UT550-□2: Relay output 3 points

UT550-□3: Relay output 3 points, transistor output 4 points

UT550-□4: Relay output 3 points

However, when a relay is not used for control output, the relay for control output can be used for the alarm 4. For this reason, the number of relay output points can be changed to 4 by adding to the above 3.

Relay contact rating: 240 V AC, 1 A or 30 V DC, 1 A

Transistor contact rating: 24 V DC, 50 mA

**● Display Specifications**

Measured value (PV) display:

5-digit 7-segment red color LED display;  
height of letters 20 mm

Data display: 3 digits + 5 digits, 7-segment red color  
LED display; height of letters 9.3 mm

Status indicator lamps: LEDs

**● Conformance to Safety and EMC Standards**

Safety standard:

Conforms to IEC1010-1: 1990 and EN61010-1: 1992

Certified for CSA1010

The overvoltage category of each input is

CAT II (IEC1010-1)

Certified for UL508 application

EMC standards:

To the following EMC standards. During test, the controller continues to operate with the measurement accuracy within  $\pm 20\%$  of the range:

For EMI (emission), EN55011, Class A Group 1

For EMS (immunity), EN50082-2: 1995

**● Construction, Installation, and Wiring**

Construction: Dust-proof and Drip-proof front panel conforming to IP55.

For side-by-side close installation, the controller loses its dust-proof and drip-proof protection.

Material of the body: ABS resin and polycarbonate

Case color: Black

Weight: About 1 kg or less

External dimensions: 96W × 96H × 100D (from the panel face) (mm)

Mounting: Direct panel mounting; mounting bracket, one each for upper and lower mounting

Panel cutout dimensions:  $92^{+0.8}_0$ W ×  $92^{+0.8}_0$ H (mm)

Mounting attitude:

Up to 30 degrees from horizontal; Must not face downward.

Wiring connection:

With M3.5 screw terminals (for signal, power and grounding wiring)

**● Power Supply and Isolation**

Power supply: Rated voltage 100 to 240 V AC ( $\pm 10\%$ ), 50/60 Hz

Power consumption: Max. 20 VA (Max. 8.0 W)

Data backup: Non-volatile memory. Service life about 100,000 times of writings

Withstanding voltage:

1500 V AC for 1 min. <sup>(Note)</sup>

between primary terminals and secondary terminals

1500 V AC for 1 min. <sup>(Note)</sup>

between primary terminals and ground terminal

1500 V AC for 1 min.

between ground terminal and secondary terminals

500 V AC for 1 min.

between secondary terminals

(where primary terminals stand for power and relay output terminals and secondary terminals stand for analog input and output signal terminals, voltage pulse output terminals, and contact input terminals.)

Note: The withstanding voltage is specified as 2300 V AC per minute to provide a margin of safety.

Isolation resistance:

20 M $\Omega$  or more for 500 V DC applied

between power terminals and ground terminal

Grounding: Class 3 grounding (grounding resistance of

100  $\Omega$  or less)

**Isolation Specifications**

PV input terminal:

Isolated from other input/output terminals, but not isolated from internal circuit.

Auxiliary analog input terminal:

Isolated from other input/output terminals and internal circuit.

15 V DC loop power supply terminal:

Not isolated from analog current output and voltage pulse control output, but isolated from other input/output terminals and internal circuit.

24 V DC loop power supply terminal:

Isolated from 4-20mA analog output, other input/output terminals and internal circuit.

Control output (current output or voltage pulse output) and

retransmission output: Not isolated between control output and retransmission output, but isolated from other input/output terminals and internal circuit.

Relay contact control output terminals:

Isolated between contact output terminals, and from other input/output terminals and internal circuit.

Contact input terminals:

Not isolated between contact input terminals and from communication terminals, but isolated from other input/output terminals and internal circuit.

Relay contact output terminals:


Not isolated between relay contact outputs, but isolated from other input/output terminals and internal circuit.

- Transistor contact output terminals:  
Not isolated between transistor contact outputs, but isolated from other input/output terminals and internal circuit.
- RS-485 communication terminals:  
Not isolated from contact input terminals, but isolated from other input/output terminals and internal circuit.
- Feedback slidewire resistance input terminals:  
Not isolated from control output terminals (current or voltage pulse output) and retransmission output, but isolated from other input/output terminals and internal circuit.
- Power terminals:  
Isolated from other input/output terminals and internal circuit.
- Ground terminal:  
Isolated from other input/output terminals and internal circuit.


### ● Environmental Conditions

- Normal operating conditions:
- Ambient temperature: 0 to 50°C (40°C or less for side-by-side close mounting )
  - Temperature change rate limit: 10°C/h or less
  - Ambient humidity: 20 to 90% RH (no condensation)
  - Magnetic field: 400 A/m or less
  - Continuous vibration (5 to 14 Hz):  
Peak-to-peak amplitude 1.2 mm or less
  - Continuous vibration (14 to 150 Hz):  
4.9 m/s<sup>2</sup> or less
  - Short-period vibration: 14.7 m/s<sup>2</sup>, 15 s or less
  - Shock: 147 m/s<sup>2</sup> or less, 11 ms
  - Installation altitude: 2000 m or less above sea level
  - Warm-up time: 30minutes or more after power on
- Transportation and storage conditions:
- Temperature: -25 to 70°C
  - Temperature change rate: 20°C/h or less
  - Humidity: 5 to 95% RH (no condensation)
- Effects of operating conditions
- Effect of ambient temperature:
- Whichever is greater,  $\pm 1 \mu\text{V}/^\circ\text{C}$  or  $\pm 0.01\%$  of F.S./°C for voltage or thermocouple inputs.
  - $\pm 0.02\%$  of F.S./°C for Auxiliary input
  - $\pm 0.05^\circ\text{C}/^\circ\text{C}$  (ambient temperature) or less for RTD inputs.
  - $\pm 0.05\%$  of F.S./°C or less for analog outputs.
- Effect of power supply fluctuation (within rated voltage range):
- Whichever is greater,  $\pm 1 \mu\text{V}/10 \text{ V}$  or  $\pm 0.01\%$  of F.S./10 V for analog inputs.
  - $\pm 0.05\%$  of F.S./10 V or less for analog outputs.


## Function Block Diagram for Single-loop Control (Model UT550-0□ ,UT550-2□ or UT550-3□)




\* Unavailable when control output is current or pulse.



**■ Function Block Diagram for Single-loop Heating/Cooling Control (Model UT550-2□)**




## ■ Function Block Diagram for Single-loop Position-proportional Control (Model UT550-1□ or UT550-4□)




④③ - ④④ terminals : 24VDC loop power supply


### Function Block Diagram for Cascade Control





## Function Block Diagram for Loop Control for Backup



\*1 Unavailable when control output is current or pulse.




## Function Block Diagram for Loop Control with PV Switching













# UT550 Single-loop Position Proportional Control (Model UT550-1□ or UT550-4□), Terminal Arrangements




# UT550 Cascade Control, Terminal Arrangements

\*Wiring can only be carried out for controllers with 24 V DC loop power supply.




**CAUTION**  
Before carrying out wiring, turn off the power to the controller and check that cables to be connected are not alive with a tester or in the like because there is a possibility of electric shock.

**NOTE**  
Installation category (overvoltage category): III (IEC1010-1)




\* Factory-set to "PV retransmission."  
Load resistance: 600 Ω or less  
\* Retransmission output 1 is not available if a 15 V DC loop power supply is used.

\* The functionality of a contact input can be varied by changing the setting of the contact input registration parameter.



Relay contact rating: 240 V AC, 1 A  
30 V DC, 1 A (resistance load)  
Transistor contact rating: 24 V DC, 50 mA




Note: External Contact Input  
If the power is turned on when the external contact input (either of Cascade, Automatic, and Manual) is ON, the controller judges that the external contact input is changed to ON.


\* OT2 is a setup parameter. You can change the settings of the parameter OT2 to change the control output type.

Correspondence between parameter OT2 and control output types	
OT2=0 (factory-set default)	OT2=1
Time proportional control Relay output (terminals ①, ② and ③)	Time proportional control Voltage pulse output (terminals ④ and ⑤)
OT2=2	OT2=3
Current output (terminals ⑥ and ⑦)	On-off control Relay output (terminals ⑧, ⑨ and ⑩)

# UT550 Loop Control for Backup, Terminal Arrangements




■ Receiving 4-20 mA DC Current Signals with the Controller  
 \* When receiving 4-20 mA DC current signals, set the PV input type to 1-5 V DC (sepoint "41").



Note: Connecting a 250  $\Omega$  resistor to the terminals is optional.  
 Model: X010-250-2 (resistor with M3.5 crimp-on terminal lugs)

**NOTE**  
 Installation category (overvoltage category): II (IEC:010-1)

\* Factory-set to "PV retransmission."  
 Load resistance: 600  $\Omega$  or less  
 \* Retransmission output 1 is not available if a 15 V DC loop power supply is used.




Note: Select this option from the OT1 parameter. If "On" is selected, the "retransmission type" is set as the type of control output.

\* OT1 is a setup parameter. You can change the settings of the parameter OT1 to change the control output type.



Correspondence between parameter OT1 and control output types	
OT1=0 (factory-set default)	OT1=1
Time proportional control Relay output (terminals ①, ② and ③)	Time proportional control Voltage pulse output (terminals ⑥ and ⑦)
OT1=2	OT1=3
Current output (terminals ⑧ and ⑩)	On-off control Relay output (terminals ①, ② and ③)

\* The functionality of a contact input can be varied by changing the setting of the contact input registration parameter.




Note: External Contact Input  
 If the power is turned on when the external contact input is OFF, the mode (SPN, RL, or A/M) existing before the power is turned off will be continued. (except for RUN/STOP)

# UT550 Loop Control with PV Switching, Terminal Arrangements



**NOTE**  
 Installation category (overvoltage category): II (IEC1010-1)




\* OT1 is a setup parameter. You can change the settings of the parameter OT1 to change the control output type.

Correspondence between parameter OT1 and control output types	OT1=1	OT1=2	OT1=3
OT1=0 (factory-set default)	Time proportional control Voltage pulse output (terminals ⑩ and ⑪)	Current output (terminals ⑬ and ⑭)	On-off control Relay output (terminals ①, ② and ③)


**Note:** External Contact Input  
 If the power is turned on when the external contact input is OFF, the mode (SPN, R/L, or A/M) existing before the power is turned off will be continued. (except for RUN/STOP)

External Dimensions and Panel Cutout Dimensions


Unit: mm



General installation



Side-by-side close installation



"N" stands for the number of controllers to be installed. However, the measured value applies if  $N \geq 5$ .

## ■ Model and Suffix Codes

Model	Suffix Code	Description
UT550		Digital indicating controller (provided with retransmission output and 15 V DC loop power supply as standard)
Type	-0	Standard type
	-1	Position proportional type
	-2	Heating/cooling type
	-3	Standard type (with 24 V DC loop power supply)
	-4	Position proportional type (with 24 V DC loop power supply)
Optional functions	0	None
	1	With communication, auxiliary analog (remote) input, 6 additional DIs and 4 additional DOs
	2	With communication, auxiliary analog (remote) input, and 1 additional DI
	3	With 5 additional DIs and 4 additional DOs
	4	With auxiliary analog (remote) input and 1 additional DI

Standard accessories: Brackets (mounting hardware), unit label, User's Manuals, and User's Manual (reference) (CD-ROM version).

Specify the required optional function codes according to the UT mode to be used.

### Correspondence between UT mode and suffix code

UT mode	Suffix code	Suffix code						Remarks
		00, 03, 20, 23, 30, 33	01, 02, 04, 31, 32, 34	10, 13, 40, 43	11, 12, 14, 41, 42, 44	21, 22, 24		
Single-loop control (UT mode 1)	Cond.	App.	Cond.	App.	App.	Cond.: Remote target setting not available The remote target setting function requires the auxiliary analog input (optional function) to be specified.		
Cascade primary loop control (UT mode 2)	N/A	App.	N/A	N/A	Cond.	Cond.: UT mode 2 not available UT mode 2 can be used if one output is specified without employing heating/cooling (two outputs) functions.		
Cascade secondary loop control (UT mode 3)	N/A	App.	N/A	App.	App.			
Cascade control (UT mode 4)	N/A	App.	N/A	App.	App.	Auxiliary analog input is used for the cascade input.		
Loop control for backup (UT mode 5)	N/A	App.	N/A	App.	App.	Auxiliary analog input is used for the tracking input.		
Loop control with PV switching (UT mode 6)	N/A	App.	N/A	App.	App.	Auxiliary analog input is used for the PV input 2.		
Loop control with PV auto-selector (UT mode 7)	N/A	App.	N/A	App.	App.	Auxiliary analog input is used for the PV input 2.		
Loop control with PV-hold function (UT mode 8)	Cond.	App.	Cond.	App.	App.	Cond.: Remote target setting not available The remote target setting function requires the auxiliary analog input (optional function) to be specified.		

App.: Function available, Cond.: Function available conditionally, N/A: Function not available

## ■ Correspondence between the Model and Suffix Codes, and the Contact Input/Output Terminals Provided

Check the model ordered and the presence/absence of contact inputs and outputs in the following table.

✓ indicate that the contacts are available.

Model and Suffix Codes	Contact input terminals								Contact output terminals						
	DI1	DI2	DI3	DI4	DI5	DI6	DI7	DI8	DO1	DO2	DO3	DO4	DO5	DO6	DO7
UT550-□0	✓	✓							✓	✓	✓				
UT550-□1	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
UT550-□2	✓	✓						✓	✓	✓	✓				
UT550-□3	✓	✓	✓	✓	✓	✓	✓		✓	✓	✓	✓	✓	✓	✓
UT550-□4	✓	✓						✓	✓	✓	✓				

## ■ Items to be Specified When Ordering

Model and suffix codes, necessary/unnecessary of User's Manual or QIC.